




Graphic Pen Display

Artist 15.6 Manual

Windows 10, 8 & 7 Mac 10.10 or above



XP-PEN

Website: www.xp-pen.com

Mail: service@xp-pen.com

Please contact us with any questions



Artist 15.6 User Manual

Safety Precautions

This manual uses the following symbols to ensure that the XP-PEN Tablet is used correctly and safely. Be sure to read and observe the Safety Precautions.



Do not use this product in a control system area that requires a high degree of safety and reliability.

In such a system, this product could negatively affect other electronic devices and



Turn the power off in areas where use of electronic devices is prohibited.

Turn the power off your tablet when onboard an aircraft or in any other location where use of electronic devices is prohibited, otherwise it may negatively affect other electronic devices in the area.



Keep the product away from infants and young children.

Accessories to this gadget may present a choking hazard to small children. Keep all accessories away from infants and young children.



CAUTION

Do not place this product on unstable surfaces.

Avoid placing this product on unstable, tilted surfaces or any locations exposed to excessive vibrations. This may cause the tablet to fall or impact surfaces which can

Do not place heavy objects on top of this product.

Do not place heavy objects on the product. Do not step on, or place your body weight on this product as this may cause damage.



Avoid extreme high or low-temperature exposure to the XP-Pen tablet.

Do not store this product in areas that drop below 5°C or above 40°C. Avoid locations with excessive temperature fluctuations. This may result in damage to the product and



Do not disassemble

Do not disassemble or modify this product. Doing so may expose you to heat, fire,



Do not use alcohol for cleaning

Never use alcohol, thinner, benzene or other mineral solvents that may discolor and cause deterioration to the product.



Do not expose to water

Be cautious of water and all liquids that may be near the tablet. Exposure to water or



CAUTION

Avoid placing metallic objects and especially magnetic objects on the tablet.

Placing metallic and/or magnetic objects on this product during operation may cause malfunction or permanent damage.



Do not strike the pen against hard objects.

Striking the pen against hard objects can cause damage to the pen.



Avoid gripping the pen too tightly, and DO NOT use excessive weight/pressure on the Express Key button and pen.

The stylus pen is a high-precision instrument. Avoid pressing too tightly on the Express Key button, and keep any objects from covering the pen to avoid potential damage. Keep the pen away from areas of high dust, contaminants, or any particulate

Limitation of Liability

- XP-Pen shall in no event be liable for damages resulting from fires or earthquakes, including those caused by third parties and those arising from user misuse, abuse or neglect.
- XP-Pen shall in no event be liable for incidental damages- including but not limited to loss of business income, interruption of business activities, corruption or loss of data – that arise from use or failure to use this product correctly.
- XP-Pen shall in no event be liable for damage resulting from uses not documented in this manual.
- XP-Pen shall in no event be liable for damages or malfunction arising from the connection to other devices or use of third party software.

Artist 15.6 User Manual

Contents

I. Artist 15.6	2
a. System requirements.....	2
b. Product overview.....	2
c. Active area.....	2
II. Stylus	3
a. Stylus and accessories.....	3
b. Pen tip replacement.....	3
c. Pen stand.....	4
III. Connecting the Artist 15.6	4
IV. Driver Installation	5
a. Windows.....	6
b. Mac.....	7
V. Driver Settings UI	12
a. Windows.....	12
b. Mac.....	17
VI. Driver Uninstallation	21
a. Windows.....	21
b. Mac.....	21

{ I.Product Overview }

a.System Requirements

- Windows 10, 8 and 7
- Mac OSX 10.10 or later
- USB and HDMI ports

b.Product Overview




Image 1-1: Product Overview

1. Working area
2. Shortcut keys
3. USB port
4. Brightness up
5. Brightness down
6. Power indicator LED
 - a. On, blue: The Artist 15.6 is connected to your computer and powered on.

c.Active area




Image 1-2: Active area

{ II. Stylus }

a. Stylus and accessories




Image 2-1: Stylus and Accessories

1. Barrel button 2
2. Barrel button 1
3. Pen tip
4. Pen stand (Top)
5. Replacement pen tips
6. Pen stand bottom
7. Pen clip hole

Notes:

(1). Barrel button functions can be customized in the tablet's driver settings.

b. Pen tip replacement




Image 2-2: Pen Tip Replacement

1. Turn the pen stand upside-down and insert the stylus tip into the hole in its center. Tilt the stylus slightly so that the tip catches on the edge of the hole, then pull the stylus and pen stand apart to remove the pen tip.
2. Twist the pen stand's top half counter-clockwise to separate it from the bottom.
3. Take a new pen tip from the inside of the pen stand.
4. Push the new pen tip straight into the stylus.

c. Pen Stand




Image 2-3: Pen Stand

{ III. Setting up the Artist 15.6 }

Notes:

- (1). Two USB cords are included with the Artist 15.6. The RED USB code of the two comes in two separate sections which must be connected before use.
- (2). The RED USB cord can be plugged into your computer or into a wall outlet. The other USB

1. The RED USB cord plugs into extra USB cable.




Image 3-1: Connecting the extra USB cable

2. Plug the USB cord into the Artist 15.6.
3. Plug the Artist 15.6 HDMI and USB cords into your computer.



Image 3-2: Connection

4. Plug the long, 2-part USB power cord into your computer or into a wall outlet. If your tablet does not work correctly with its power cord connected to your computer, please plug the




Image 3-3: Connection-1

Notes:

- If your tablet displays a “No Signal” error message:
 - (1). Unplug the Artist 15.6’s USB cord then plug it back in. Ensure that cord is connected well. Reboot your computer, then turn the Artist 15.6 off and back on.
 - (2). Test the Artist 15.6 on a different computer to check for hardware issues.
 - (3). If the error persists on different computers and (a) does not solve it, please contact XP-PEN

{ IV.Driver Installation }

Notes:

- (1). Disable any antivirus or firewall software and close any non-essential background software before beginning the installation. Some software, such as OneDrive and Dropbox, may monopolize important files and prevent a successful installation. On Windows computers, check the system tray on the bottom-right of the screen and close any software unrelated to your computer hardware. On Windows 8 computers, syncing must be disabled in OneDrive while installing and uninstalling tablet drivers.
- (2). Uninstall any existing tablet software before attempting to install the Artist 15.6 driver. Other tablet drivers will conflict with the Artist 15.6 driver or prevent installation entirely.

- (3). You can download the latest driver from the XP-Pen website (www.xp-pen.com). Extra the .zip file contents before running “.exe” or “.pkg.”
- (4). The Artist 15.6’s maximum resolution is 1920x1080.

a.Windows

1. Connect the Artist 15.6 to your computer using the included HDMI & USB cords. Turn on the tablet.
2. Please download the Artist 15.6 latest driver from the support section of our website, www.xp-pen.com. Extra the “.zip” file contents before running “.exe”.
3. After a successful installation, the driver’s icon (🖥️) will appear in your system tray and on your desktop. If the icon is not present, uninstall the driver, reboot, and repeat step 2.
4. (Recommended) Open [Control Panel] > [Display], then set Change the size of text, apps, and other items to 100%.




Image 4-1: Display setting

5. In [Control Panel] > [Display], change your dual monitor settings to Extend mode/Extend these displays.
6. In Extend mode, set your Artist 15.6 to monitor 2 and choose a resolution of 1920x1080.
7. In Duplicate these displays mode, set both of your monitors’ resolutions to 1920x1080.




Image 4-2: Extend mode

8. Apply and exit.
9. Double-click the driver's system tray icon to open your tablet settings, then set your Artist 15.6 to *Monitor 2* under "Current screen." Apply and exit.

b. Mac

1. Connect the Artist 15.6 to your computer using the included HDMI & USB cords. Turn on the tablet.
2. Please download the Artist 15.6 latest driver from the support section of our website, www.xp-pen.com. Extra the ".zip" file contents before running ".pkg".



Image 4-3: Mac driver

3. If you run into the error message below, please complete the following steps.




Image 4-4: Unidentified developer

- (1). Open "System Preferences," then "Security & Privacy."



Image 4-5: Security & Privacy

- (2). Click the lock icon on the bottom left of the window.




Image 4-6: Lock

(3). Input your username and password, then click "Unlock."




Image 4-7: Password

(4). Click "Open Anyway."




Image 4-8: Open Anyway

(5). Click "Open" to run the tablet setup.




Image 4-9: Open

4. Open [System Preferences] > [Display]. In the Display tab, set your resolution to Default for display.



Image 4-10: Display




Image 4-11: Arrangement

5. In the Arrangement tab, you may choose to Mirror Displays. With Mirror Displays enabled, both monitors' resolutions should be set to 1920x1080.
 - (1). Open [Finder] > [Applications] > [Touch Tablet] > [Pen Tablet Setting].
 - (2). In the Calibration tab, set Monitor Mapping to Monitor 1.
6. With Mirror Displays disabled, set your Artist 15.6's resolution to 1920x1080.
 - (1). Open [Finder] > [Applications] > [Touch Tablet] > [Pen Tablet Setting].




Image 4-12: Calibration

{V.Driver Settings UI}

a. Windows

The Artist 15.6's driver settings can be opened in two ways:

- Double-click the driver's system tray icon (1).
- OR
- Double-click the "Pentablet" icon on your desktop.

Driver UI




Image5-1: UI

You may customize the functions of your tablet pen's barrel buttons here. Use the "Function Key" option to program custom keystrokes.

1. Barrel Button Settings

You may customize the functions of your tablet pen's barrel buttons here. Use the "Function Key" option to program custom keystrokes.




Image5-2: Barrel Button Settings

Note:

Pen/Eraser Toggle

With the stylus in range of the Artist 15.6's working area, press the assigned barrel button to toggle between pen and eraser modes in compatible drawing software. The current mode will briefly be displayed on your monitor.

2. Click Sensitivity & Current Pen Pressure

You can adjust pen pressure to "Output" or "Press" sensitivity on here.

Current Pen Pressure shows the current pressure level being exerted on your tablet and can be used to test pen pressure.




Image 5-3: Click Sensitivity

3. Mouse Mode

Absolute (Pen) Mode: Standard tablet mode; Each point of the tablet's work area corresponds to an absolute point on your computer display.

Relative (Mouse) Mode: Mouse mode; The tablet's work area does not correspond to absolute




Image5-4: Absolute & Relative modes

4. Current Screen

The Artist 15.6 may be configured for use on different monitors. Generally, this should be set to "Monitor 2."



Image5-5: Current Screen

5. Windows Ink

Windows Ink capability can be toggled on and off here. Enabling this will allow support for



Image5-6: Windows Ink

6. Calibration

The Calibration tab allows you to set up calibration for your tablet.




Image5-7: Calibration

7. Display Setting

- (1). Color Temperature: Use to adjust the Artist 15.6's color balance.
- (2). User: Use to adjust red, green and blue color levels on the Artist 15.6's display. Brightness and contrast can also be adjusted here.




Image5-8: Display Setting

8. Express Keys Settings




Image5-9: Express Key Setting

Use Function Key to set custom keystrokes for your shortcut keys.




Image5-10: Function Key

Note:
Fine Detail Mode allows you to restrict your tablet's active area to a small portion of the screen for fine detailing.

9. Default
Click "Default" to revert to manufacturer settings.

10. XP-Pen Logo
If a driver update is available, you will see a blue arrow here (). Click the arrow to update your driver.



Image5-11: XP-Pen logo

b. Mac

To open the Artist 15.6's driver settings, open Finder > Applications > PenTabletSetting.



Image5-12: Tablet Setting

Driver UI

1. Pen




Image5-13: Pen tab

In this tab, you may customize the functions of your stylus's barrel buttons, adjust pressure sensitivity, and test your pen pressure.

Lighter sensitivity means that digital pressure level will rise with less applied physical pressure.

Click "Default Button Setting" to revert to manufacturer settings.

Note:
Pen/Eraser Toggle
(1). With the stylus in range of the Artist 15.6's working area, press the assigned barrel button to toggle between pen and eraser modes in compatible drawing software. The current mode




Image5-14: Barrel button settings




Image5-15: Pressure Test

2. Express Keys

Notes:

- (1). The Artist 15.6's shortcut keys are designed to work with US English keyboards.
- Keys may not function correctly with other keyboard languages.
- (2). By default, the Artist 15.6's express keys are mapped to standard Photoshop keyboard shortcuts. Keys can be customized to function efficiently in other software.
- The Artist 15.6's shortcut keys can be customized in this tab. Click Default to revert to manufacturer settings.

You may choose a key's function from a preset list, or click Reset Customer Defined for advanced



Image5-16: Express Keys

3. Calibration

The Calibration tab allows you to calibrate your tablet, map your monitor, or rotate your display.

To calibrate, click *Calibration ...* and follow the on-screen instructions.




Image5-17: Calibration

4. About




Image5-18: About

{ VI. Driver Uninstallation }

a. Windows

In the Start menu, open [Settings] → [Apps & features]. Find “PenTablet” and click “Uninstall.” Follow the on-screen instructions.

b. Mac

Open [Finder] → [Application] → [Pen Tablet], then click “Uninstall Pen Tablet” and follow the on-screen instructions.




Image 6-1: Mac uninstall

Note:

When attempting to reinstall the Artist 15.6 driver, be sure to reboot your computer after the

{ VII.FAQ }

Q: Where can I download the latest Artist 15.6 driver?

a. Latest driver releases can be downloaded from our website (www.xp-pen.com).

Q: I can't use the stylus to control the cursor.

a. Uninstall the Artist 15.6 driver and reboot, then connect your Artist 15.6 to your computer and test your stylus. If the cursor responds to your pen input, the tablet's hardware is functional. Reinstall the Artist 15.6 driver according to these steps (Windows):

Download the tablet's latest driver from www.xp-pen.com, then extract the .zip contents to the desktop.

Close all non-essential software and processes (Some software may use the wintab process and interfere with the driver installation. OneDrive in particular often causes issues; its system tray icon looks like two grey clouds. OneDrive's syncing must be disabled during installation and uninstallation on Windows 8 computers).

Open C:\Windows. Using the "search" box near the top-right of the window, search for "WinTab32.dll" and delete any instances.

Connect the tablet and power it on, then run the driver installation. Complete the

Q: How do I know that the Artist 15.6 driver installed successfully?

a. After installing the driver, the Artist 15.6's driver icon should be visible in your system tray on the bottom-right of your screen (Windows OS). Pen input will control the cursor and pressure sensitivity will be functional in the driver UI's "Pressure Test".

Q: How do I determine if a problem is software or hardware related?

a. Connect and install the Artist 15.6 on a different computer. If the tablet functions properly on the new computer, you are experiencing a software issue—confirm that ALL tablet drivers (including the Artist 15.6) are uninstalled and removed from your computer, then reinstall the Artist 15.6.

If you have any questions, please contact us at:

Skype: XP-Pen

Web: www.xp-pen.com

Email: service@xp-pen.com