


How to update G640S' firmware

- Please make sure you have connected G640S into your windows computer and can use stylus to control cursor.
- Extract “*G640S firmware.zip*” then open folder to run “*UgeeBootLoader.exe*”
- Click “*OneKeyUpdate*” button.



- When update completed, please click “*OneKeyUpdate*” and “X” to exit.

