




M Multi-functional Drawing Tablet Stand

English、Русский язык、日本語、中文
Deutsch、한국어、Español、Français



XP-PEN

Any questions, please contact us

Skype: XP-Pen
Web site: www.xp-pen.com
Mail: service@xp-pen.com



User Manual


Thank you for purchasing the XP-Pen Multi-functional Drawing Tablet Stand. Our product quick guide is currently available in English, Russian, Japanese, German, Korean, Chinese, Spanish, and French. We apologize if your preferred language is not supported.

Contents


English.....	1-2
中文.....	3-4
日本語.....	5-6
Русский язык.....	7-8
한국어.....	9-10
Español.....	11-12
Français.....	13-14
Deutsch.....	15-16

The XP-Pen Adjustable Multi-functional Display and Tablet Stand


Instructions:




① Foldable Stand Base ② Adjustable release switch ③ Open/Close Finger Slot
④ Stand Wall ⑤ anti-skid pad




1. Place the Multi-Display Stand on a flat, stable surface . Open the ① Foldable Stand Base.




2. To open the adjustable Stand Wall/Base: Press and Hold the ② Adjustable release switch and place your finger in the ③ Open/Close Finger Slot to pull the stand open.



3. To adjust the angle of the stand, place your finger in the ③ Open/Close Finger Slot and hold down the ② Adjustable release switch. The stand can be adjusted freely. Release the Adjustable release switch to lock the stand in place.



4. Place your preferred device onto the ① Foldable Stand Base and ④ Stand Wall



5. To close the Display Stand: press and hold the ② Adjustable release switch and guide the Stand Wall into its resting position with a finger in the ③ Open/Close Finger Slot.

***To avoid injury, DO NOT place your hand or fingers between the Foldable Stand Base and Stand Wall while opening/closing/adjusting the Display Stand.**



If you have any questions, please contact us at:

Skype: XP-Pen

Web: www.xp-pen.com

Email: service@xp-pen.com